



Instruction

To be assembled by adults only
3623 DISHWASHER




WARNING :
The toy is to be assembled by an adult.
Some Parts of this product are small.
Keep out of baby's reach.


1




2




Parts List




Hardware List




3




4




5



6



7



8

